

Manual, Assembly instruction: Brodit 655083

Center mount

1.)



2.)



3.)



4.)



Read all of the instructions and look at the pictures before attaching the ProClip. It is important to place this ProClip exactly in the same position as shown in the pictures.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the upper part of the ProClip into the gap between the air vent and the surrounding frame. Adjust the ProClip sideways so the angled edge goes all the way into the gap.

2. Press the lower part of the ProClip upward and forward. Hook the angled lower edge of the ProClip into the gap between the air vent and the surrounding frame.

3. Press upward on the upper part of the ProClip and downward on the lower part of the ProClip so the adhesive tapes attach properly.

4. The ProClip is in place.