

Manual, Assembly instruction: Brodit 655136

Angled mount ONLY for Comfort Dashboard WITHOUT a lid on the middle storage pocket.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Hold the ProClip vertically so the s-shaped lower edge can be inserted into the gap between the lighter and darker part of the dashboard.
2. Move the top part of the ProClip upward/forward so the lower part goes all the way into the gap and hooks behind the panel.
3. Hook the angled upper edge of the ProClip into the lower edge of the air vent.
4. The ProClip is in place.