

Manual, Assembly instruction: Brodit 655138

Center mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip. This ProClip can be placed along the full width of the dash.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Insert the thin end of the enclosed Gap Opener (Spaltöffner) into the lower gap between the paneling surrounding the air vents and the remainder of the dashboard, to widen the gap.

2. Insert the lower edge of the ProClip into the gap next to the Gap Opener (Spaltöffner). Remove the Gap Opener (Spaltöffner).

3. Insert the thin end of the Gap Opener (Spaltöffner) into the upper gap between the paneling surrounding the air vents and the remainder of the dashboard, to widen the gap. While keeping pressure on the Gap Opener (Spaltöffner), press the angled upper edge of the ProClip into the gap next to the Gap Opener (Spaltöffner). Remove the Gap Opener (Spaltöffner).

4. The ProClip is in place.