

Manual, Assembly instruction: Brodit 655159

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Press the angled left edge of the ProClip into the gap between the air vent frame and the frame surrounding the storage cubby.

2. Move the ProClip rightward so the angled left edge hooks behind the storage cubby frame. Hook the angled right edge of the ProClip around the left edge of the air vent frame. Press the ProClip forward to make sure the adhesive tape attaches properly.

3. The ProClip is in place.

4. The ProClip is in place.