

Manual, Assembly instruction: Brodit 655173

Center mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip. This ProClip can be mounted along the full width of the dashboard.

1. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap dividing the center console, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip.

2. Insert the angled upper edge of the ProClip into the gap next to the Gap Opener (Spaltöffner). Hook the angled upper edge into the gap by pressing it forward and at the same time move the lower part forward. Remove the Gap Opener (Spaltöffner).

3. Press the lower part of the ProClip upward so the milled lower edge goes into the lower part of the air vent and the adhesive tape fastens.

4. The ProClip is in place.