

Manual, Assembly instruction: Brodit 655182

Center mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Insert the angled upper edge of the ProClip into the second row of the air vent on the top of the dash.
2. Pull the ProClip toward you so the angled upper edge goes all the way into the air vent and the lower part flexes towards you.
3. Insert the angled lower edge of the ProClip into the gap on the upper inside of the air vent.
4. The ProClip is in place.