

Manual, Assembly instruction: Brodit 655204

Center mount ONLY for Premium Dashboard WITH a lid on the middle storage pocket.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip. This ProClip can also be placed on the passengers side airvent, but must be placed according the the pictures.

- 1.** Insert the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the frame surrounding the top part of the center console and the remainder of the dashboard, to widen the gap.
- 2.** Insert the angled lower edge of the ProClip into the gap below the frame surrounding the center information display. Make sure the ProClip aligns according to the picture. Slide the ProClip rightward so it aligns just above the Air Bag and hazard lights buttons, according to the picture. Make sure the angled edge goes all the way into the gap.
- 3.** Insert the upper angled edge of the ProClip into the gap next to the Gap Opener (Spaltöffner). Remove the Gap Opener (Spaltöffner).
- 4.** The ProClip is in place.