

Manual, Assembly instruction: Brodit 655245

Center mount



Please read all of the instructions and look at the pictures before installing the ProClip. Important: This ProClip will visually block the clock.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Insert the thin end of the enclosed gap openers into the gap between the airvents below the information display and the padded part of the dash, to widen the gap. Make sure to place the gap openers on either side of the clock.

2. Insert the upper angled edge of the ProClip into the gap between the gap openers. Remove the gap openers.

3. Insert the thin end of one of the gap openers in the gap between the panel surrounding the air vents and the climate control panel. Press the ProClip downward and insert the lower angled edge into the gap next to the gap opener. Remove the gap opener.

4. The ProClip is in place.