

Manual, Assembly instruction: Brodit 655273

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Open the glove compartment. Press the angled edge on the left part of the ProClip into the gap between the glove compartment and the dashboard.

2. Flip the ProClip rightwards so the left angled edge hooks behind the glove compartment.

3. Press the thin end of the enclosed gap opener into the gap between the control panel and the center console frame, to widen the gap. Press the right edge of the ProClip into the gap above the gap opener. Press forward on the right part of the ProClip so the edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.