

Manual, Assembly instruction: Brodit 655280

Center mount, Low

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the curved edge on the left part of the ProClip into the gap between the frame surrounding the control panel and the frame surrounding the air vent. Flip the ProClip rightwards + forwards so the curved left edge hooks behind the frame surrounding the control panel.
3. Press forward on the right side of the ProClip so the angled edge hooks into the gap below the Gap Opener (Spaltöffner). Press until you hear + feel it snaps into place. Pull out the Gap Opener (Spaltöffner).
4. The ProClip is in place.