

Manual, Assembly instruction: Brodit 655297

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Insert the thin end of the enclosed gap opener into the gap between the frame surrounding the center console panel and the dash, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Insert the angled lower edge of the ProClip into the gap next to the gap opener.

2. Flex the upper edge of the ProClip and push it forward/downward until the angled upper edge aligns onto the top of the dash. Remove the gap opener.

3. Insert the thin end of the gap opener into the gap on the forward edge of the dash, to widen the gap. Hook the angled upper edge of the ProClip into the gap next to the gap opener. Remove the gap opener.

4. The ProClip is in place.