

Manual, Assembly instruction: Brodit 655303

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip can also be placed by the left air vent.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap above the dashboard, to widen the gap between the dashboard and the compartment. Peel off the cover of the adhesive tape on the ProClip. Hook the angled edge on the lower part of the ProClip under the frame surrounding the air vent.

2. Press the upper part of the ProClip forward so the curved edge hooks into the gap next to the gap opener.

3. Press the upper edge of the ProClip all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.