

Manual, Assembly instruction: Brodit 655320

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Press the angled edge of the lower part of the ProClip into the gap between the upper and lower section of the dashboard.

2. Rotate the ProClip upward so the angled edge on the lower part hooks behind the lower dashboard section. Press upward on the ProClip and hook the upper angled edge over the frame surrounding the air vent.

3. The ProClip is in place.

4. The ProClip is in place.