

Manual, Assembly instruction: Brodit 655325

Angled mount ONLY for models with CD slot.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the right corner on the lower part of the ProClip into the gap between the frame surrounding the CD slot and the dashboard.
2. Press the lower part of the ProClip upward so all of the angled edge goes into the gap.
3. Press forward on the ProClip mounting plate and downward on top of the ProClip so the angled upper edge hooks into the gap between the frame surrounding the display and the dashboard. Press downward on the upper part of the ProClip so the angled edge goes all the way into the gap.
4. The ProClip is in place.