

Manual, Assembly instruction: Brodit 655326

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the left part of the ProClip inside the left part of the air vent.
2. Press forward on the right side of the ProClip so it snaps into place inside the frame surrounding the air vent.
3. The ProClip is in place.
4. The ProClip is in place.