

Manual, Assembly instruction: Brodit 655334

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the ProClip right by the center console. Press the angled edge on the lower part of the ProClip into the gap between the dashboard by the glove compartment and the center section of the dashboard. Press/Flip the ProClip upward/forward so the angled lower edge hooks behind the dashboard by the glove compartment.

2. Pull the upper part of the ProClip upward and hook the angled upper edge over the frame surrounding the air vent. Press down on top of the ProClip so the angled edge hooks properly in place and the tape attaches.

3. The ProClip is in place.

4. The ProClip is in place.