

Manual, Assembly instruction: Brodit 655358

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the thin end of the two enclosed gap openers into the gap between the padded dashboard ledge and the top of the dashboard, to widen the gap.
2. Press the lower edge of the ProClip into the gap between the padded dashboard ledge and the frame surrounding the display.
3. Press forward on the top of the ProClip and hook the J-shaped upper edge into the gap between the gap openers. Pull out the gap openers.
4. The ProClip is in place. This ProClip will also attach further to the left and right along the padded dashboard ledge.