

Manual, Assembly instruction: Brodit 655366

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to place the ProClip in the exact same position as shown in the pictures.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the dashboard and the frame surrounding the instrument panel, to widen the gap. Peel off the cover of the adhesive tape on the ProClip.
2. Press the thin angled edge of the ProClip into the gap below the gap opener.
3. Press the ProClip downward and hook the notch over the edge of the frame. Pull out the gap opener.
4. The ProClip is in place.