

Manual, Assembly instruction: Brodit 655384

Angled mount, Left



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap openers into the gap between the lower section of the dashboard and the dashboard surrounding the glove compartment, to widen the gap.
2. Press the angled edge on the upper part of the ProClip into the gap between the upper and lower section of the dashboard.
3. Press downward hard on the lower part of the ProClip so the angled edge hooks into the gap between the gap openers. Press upward on the lower part of the ProClip so the angled edge goes all the way into the gap. Pull out the gap openers.
4. The ProClip is in place.