

Manual, Assembly instruction: Brodit 655385

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the control panel and the center console sidewall, to widen the gap. Peel off the adhesive tape cover on the ProClip. Hook the right edge of the ProClip, with adhesive tape, over the frame surrounding the control panel.

2. Press forward on the left side of the ProClip, so the angled edge hooks into the gap above the gap opener.

3. Press the left part of the ProClip toward the center console so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.