

Manual, Assembly instruction: Brodit 655387

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the lower edge of the ProClip under the dashboard overhang.
2. Flex the upper part of the ProClip upward and hook the angled edge over the padded dashboard.
3. Press down on the upper edge of the ProClip so it goes all the way into the gap.
4. The ProClip is in place.