

Manual, Assembly instruction: Brodit 655395

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the angled edge of the ProClip under the frames surrounding the air vents. Press the front part of the ProClip downward so the angled back edge hooks under the frames surrounding the air vents, and rests on the dashboard.
2. Press the ProClip forward/downward. Hook the angled front edge of the ProClip under the frame surrounding the control panel.
3. This ProClip can also be placed by the left air vent.
4. The ProClip is in place.