

Manual, Assembly instruction: Brodit 655397

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the upper edge of the ProClip into the gap between the frame surrounding the display and the trim. Press/Flip the ProClip downward so the upper edge hooks under the frame surrounding the display.
2. Hook the lower edge of the ProClip under the panel surrounding the air vents.
3. The ProClip is in place.
4. The ProClip is in place.