

Manual, Assembly instruction: Brodit 655401

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts Part 1. Attaching part (the smallest part) Part 2. Mounting plate

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the angled edge on Part 1 into the gap between the control panel and the surrounding frame.

2. Press forward on Part 1, in the same time press leftwards so the angled edge hooks behind the control panel.

3. Peel off the adhesive tape cover on Part 1. Place Part 2 onto Part 1 so the holes match. Screw Part 2 onto Part 1 with the enclosed screws.

4. The ProClip is in place.