

Manual, Assembly instruction: Brodit 655406

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to place this ProClip in the exact same position as shown in the pictures.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge in the upper part of the ProClip into the upper part of the air vent, exactly centered on the air vent.

2. Press the lower part of the ProClip upward/forward and hook the angled edge on the lower part into the lower edge of the air vent.

3. The ProClip is in place.

4. The ProClip is in place.