

Manual, Assembly instruction: Brodit 655413

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the grooved edge on the upper part of the ProClip under the upper edge of the air vent.
2. Press the ProClip upward/forward and hook the grooved lower edge over the lower edge of the air vent.
3. The ProClip is in place.
4. The ProClip is in place.