

Manual, Assembly instruction: Brodit 655425

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Peel off the adhesive tape cover on the ProClip.
2. Press the angled edge on the lower part of the ProClip into the gap between the trim and the padded dashboard.
3. Press the upper part of the ProClip downward/forward. Hook the angled edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is in place.