

Manual, Assembly instruction: Brodit 655432

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Slide the ProClip over the left console post. The face plate of the ProClip should rest on top of the post. The attaching edge of the ProClip should slide under the post.

2. Press the angled edge of the upper attaching edge of the ProClip into the gap under the console post, the furthest gap closest to the drivers side.

3. Press upward on the lower part of the ProClip and hook the lower taped edge over the chrome trim on the side of the console post. Press on the lower part of the ProClip so the adhesive tape attaches properly.

4. The ProClip is in place.