

Manual, Assembly instruction: Brodit 655449

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the upper part of the ProClip upwards into the gap between the air vent and the surrounding frame.
2. Press the lower part of the ProClip upward and hook the grooved edge over the lower edge of the air vent.
3. This ProClip can also be placed by the left air vent.
4. The ProClip is in place.