

Manual, Assembly instruction: Brodit 655451

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Hook the angled edge on the upper part of the ProClip over the frame surrounding the air vent.
2. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the control panel and the frame surrounding the compartment, to widen the gap. Hook the angled edge on the lower part of the ProClip into the gap next to the gap opener.
3. Press upward on the lower part of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.
4. The ProClip is in place.