

Manual, Assembly instruction: Brodit 655457

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Align the two base parts of the ProClip onto the console side handle. Attach the two parts together with the enclosed screws.

2. Place the mounting plate onto the base parts so the holes align. Attach the face plate onto the base parts with the enclosed screws.

3. This ProClip can be installed onto both console side handles.

4. The ProClip is in place.