

Manual, Assembly instruction: Brodit 655477

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Remove the screw in the coin compartment on top of the dashboard.
2. Place the ProClip in the coin compartment so the holes match. Attach the ProClip with the screw.
3. The ProClip is in place.
4. The ProClip is in place.