

Manual, Assembly instruction: Brodit 655494

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the lower edge of the ProClip into the gap between the frame surrounding the control panel and the dashboard.

2. Press/Flip the ProClip upward/forward so the lower edge hooks behind the frame surrounding the control panel. Pull the upper part of the ProClip upward and hook the angled upper edge over the frame surrounding the air vent. Press downward on top of the ProClip so the angled edge hooks properly in place and the adhesive tape attaches.

3. This ProClip can also be placed in the right side on the center console. A device installed in this position may block the display.

4. The ProClip is in place.