

Manual, Assembly instruction: Brodit 655509

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between frame surrounding the control panel and the dashboard. Press/Flip the upper part of the ProClip upward/forward so the angled lower edge hooks behind the frame surrounding the control panel.

2. Press the upper part of the ProClip downward/forward and hook the angled upper edge into the gap between the frame surrounding the air vent and the dashboard.

3. This ProClip can also be placed onto the right air vent. A device installed in this position may block the display.

4. The ProClip is in place.