

Manual, Assembly instruction: Brodit 655517

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the upper part of the ProClip under the frame surrounding the air vent.
2. Press the ProClip upward/forward. Hook the lower edge of the ProClip over the frame surrounding the air vent.
3. This ProClip can be placed on all the air vents.
4. The ProClip is in place.