

Manual, Assembly instruction: Brodit 655568

Center mount ONLY for automatic gear shift

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the right edge of the ProClip under the center console frame.

2. Press the left edge of the ProClip into the gap between the frame surrounding the gear shift and the inner side panel so the angled edge hooks under the side panel.

3. The ProClip is in place.

4. The ProClip is in place.