

Manual, Assembly instruction: Brodit 655569

Angled mount ONLY for automatic gear shift



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the lower part of the ProClip under the edge of the center console.
2. Press the upper part of the ProClip into the gap between the panel surrounding the gear shifter and the center console frame.
3. The ProClip is in place.
4. The ProClip is in place.