

Manual, Assembly instruction: Brodit 655588

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the thin end of the enclosed gap opener into the gap in the dashboard, to widen the gap. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
2. Pull the ProClip downwards and hook the angled edge under the dashboard.
3. Press upward on the lower part of the ProClip so the adhesive tape attaches.
4. The ProClip is in place.