

Manual, Assembly instruction: Brodit 655597

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the air vent and the panel, to widen the gap, placed directly to the right of the air vent control. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener.

2. Pull out the gap opener. Slide the ProClip leftwards until it stops, placed directly to the right of the air vent control.

3. Press down on the upper part of the ProClip so it flexes. Press the upper part of the ProClip forward so the edge with adhesive tape is placed under the frame surrounding the air vent. Carefully release the pressure so the upper edge is pressed upward toward the frame surrounding the air vent. Press upward on the upper part of the ProClip so the adhesive tape attaches properly.

4. The ProClip is in place.