

Manual, Assembly instruction: Brodit 655620

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the upper part of the ProClip into the gap between the frame surrounding the air vent and the dashboard.

2. Press the lower part of the ProClip upward. Press the lower part of the ProClip forward and hook the grooved edge over the air vent.

3. This ProClip can also be attached over the right air vent. A device installed in this position may block the display.

4. The ProClip is in place.