

Manual, Assembly instruction: Brodit 655631

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the upper grooved edge under the inner frame surrounding the air vent.

2. Press the lower part of the ProClip upward/forward.

3. Hook the lower edge of the ProClip over the inner frame surrounding the air vent.

4. The ProClip is in place.