

Manual, Assembly instruction: Brodit 655657

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder + equipment is to be attached after the ProClip is in place.

1. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the dashboard and the trim, to widen the gap.
2. Press the lower angled edge on the ProClip into the gap between the control panel and the trim.
3. Press the upper part of the ProClip forward so the angled edge hooks into the gap next to the Gap Opener (Spaltöffner). Pull out the Gap Opener (Spaltöffner).
4. The ProClip is in place.