

Manual, Assembly instruction: Brodit 655689

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Press the thin end of the enclosed gap opener into the gap between the panel surrounding the screen and the dashboard, to widen the gap. Hook the angled edge on the lower part of the ProClip into the gap between the trim and the dashboard overhang over the air vent.

2. Press upward on the lower part of the ProClip so the angled edge goes into the gap.

3. Pull the upper part of the ProClip upward/forward. Hook the upper edge into the gap next to the gap opener. Press down on top of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.