

Manual, Assembly instruction: Brodit 655691

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Press the thin end of the enclosed gap opener into the gap between the air vent and the surrounding frame, to widen the gap.
2. Press the angled edge on the lower part of the ProClip into the gap between the frame surrounding the air vent and the center console.
3. Press the upper part of the ProClip forward so the angled edge hooks into the gap next to the gap opener. Press on the ProClip so the angled edges go all the way into the gaps. Pull out the gap opener.
4. The ProClip is in place.