

Manual, Assembly instruction: Brodit 655717

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Open the compartment on top of the dashboard. Press the enclosed gap opener into the gap between the compartment and dashboard, to widen the gap. Peel off the adhesive tape cover on the ProClip.

2. Hook the encled edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. Place you fingers behind the mounting plate and pull the ProClip toward you. Hook the angled lower edge into the gap between the frame surrounding the air vent and the dashboard.

4. ProClip is in place.