

Manual, Assembly instruction: Brodit 655726

Center mount, The ProClip will hide some buttons.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the frame surrounding the air vent and the control panel.

2. Press the upper part of the ProClip downward/forward. Hook the angled edge on the upper part of the ProClip into the gap between the frame surrounding the air vent and the control panel.

3. This ProClip can also be attached onto the right air vent. A device installed in this position may block the screen.

4. The ProClip is in place.