

Manual, Assembly instruction: Brodit 655733

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Hook the grooved edge on the upper part of the ProClip under the frame surrounding the air vent.
2. Press the lower part of the ProClip upward and forward. Hook the grooved edge on the lower part of the ProClip over the frame surrounding the air vent.
3. The ProClip is in place.
4. This ProClip can also be placed onto the left air vent.