

Manual, Assembly instruction: Brodit 655752

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover. Hook the grooved edge on the upper part of the ProClip under the frame surrounding the air vent.

2. Press the lower edge of the ProClip upward/forward and hook the grooved edge over the frame surrounding the air vent.

3. This ProClip can also be attached onto the left side of the center console. **4.** The ProClip is in place.