

Manual, Assembly instruction: Brodit 655754

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover. Hook the grooved edge on the lower part of the ProClip over the frame surrounding the air vent.

2. Press the ProClip downward/forward. Hook the grooved upper edge under the frame surrounding the air vent.

3. This ProClip can be placed anywhere within the width of the air vents.

4. The ProClip is in place.