

Manual, Assembly instruction: Brodit 655757

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover. Press the lower edge of the ProClip into the gap between the air vent and the surrounding frame.

2. Press the upper part of the ProClip downward/forward. Press the upper edge into the gap between the air vent and the surrounding frame.

3. View from the side.

4. The ProClip is in place.